

## Why Chronomite Laboratories Is a Perfect Match for Modular Buildings

Chronomite point-of-use water heaters are ideal for prefabrication projects.

Speed up construction, while cutting out material and labor costs

- Compact Size: Smaller than a laptop and fits well under a sink
- Simple Installation: 10–15 minutes to install a point-of-use heater
- Flexibility: Choice of install—plug-in or hard-wired
- Maintenance: Self-cleaning waterway
- Efficient: Fast hot water delivery









L1001481 06/20

