



FLEX ARRESTER™ CONNECTORS

DESIGN FEATURES

- Easy to Install
- Size AA, ASSE 1010 certified.
- No access panel or maintenance required
- May be installed at any angle
- Patented Inline Hammer Arrester eliminates water hammer
- Exceeds all ASTM A112.18.6 Flow requirements
- 5 year warranty
- 100% Lead Free Compliant
- Is effective when installed in any direction

MATERIAL SPECIFICATION

- · Corrosion resistant polymer braid
- Taste and odor free patented Ultracore™ liner
- · Chloramine resistant soft cones
- · End Fittings and Nuts, Brass
- SS Ferrule

MAINTENANCE

- · Keep hose assembly dry
- Inspect every six months and replace immediately in the event of leaks, wear, discoloration and any visible signs of corrosion
- Do not re-use

OPERATING SPECIFICATIONS

- Temperature: 40-160°F
- Max working pressure 125 PSI

CAUTION

- Keep away from Solvents/Cements/Primers
- Keep out of constant direct sunlight
- For Indoor Use Only

COMPLIANCES/LISTINGS

LISTING		ISTING	STANDARD/COMPLIANCE	
1	IAPMO	2111	ASME A112.18.6-2017/CSA B125.6-17	
2	IAPMO	4541	ASSE 1010-2004	
3	IAPMO	6545	NSF / ANSI 372 - 2016	
4	IAPMO	N-6614	NSF / ANSI / CAN 61 - 2018	
5	IAPMO	4393	IAPMO IGC 168-2012e1 (incl. req. of ASME A112.18.1/CSA B125.1 and ASSE 1010)	



PART NUMBER	NUMBER DESCRIPTION		LISTINGS			
ICE MAKER CONNECTOR – 60"						
IMFA-160-PP	1/4" Compression H.C. x 1/4" Compression H.C.	10	1,2,3,4			
DISHWASHER CONNECTOR – 60"– ARRESTER IS 12" FROM VALVE						
DWFA-160-PP	3/8" Compression S.C. x 3/8" Compression S.C. w/ 3/8" NPT 90°Elbow Adapter	10	1,2,3			
DWFA-560-PP	3/8" Compression x 3/8" Compression w/ 3/4" FGHT 90° Elbow Adapter	10	1,2,3			
WASHING MACHINE CONNECTOR – 60"						
WMFA-160-PP	3/8" I.D., 3/4" FGHT X 3/4" FGHT	10	1,2,3			
FAUCET CONNECTOR – 20"						
FCFA-120-PP	3/8" Compression x 1/2" FIP	25	1,2,3,4,5			
TOILET CONNECTOR – 12"						
WCFA-112-PP	3/8" Compression x 7/8" Ball Cock	25	1,2,3,5			

INSTRUCTIONS

- 1. Install with water flow in direction of arrow.
- 2. Position Flex Arrester to prevent damage from appliance when moved.
- 3. Hand-tighten inlet to supply valve. Add $\frac{1}{4}$ turn with wrench. Do not over tighten.
- 4. If Elbow Adaptor is needed: Use Teflon Tape on the male thread, tighten to appliance.
- 5. Hand-tighten outlet to elbow adaptor. Add ¼ turn with wrench. Do not over tighten.
- 6. Brass nuts hand-tighten outlet to appliance. Add ¼ turn with wrench. Do not over tighten.
- 7. Plastic nuts hand-tighten only. Do not over tighten.
- 8. Do not twist, kink, crush or pull line up against fitting.
- 9. After installation, check for leaks.

